



*Flächenbelastungstabelle / Table of area loading*



Startgewicht / Take of weight (kg)	50	55	60	65	70	75	80	85	90	95	100	105	110	115	120	125	130
Infinity II XS	2,0	2,2	2,4	2,6	2,8	3,0	3,2	3,4									
Infinity II S				2,4	2,6	2,8	3,0	3,2	3,4								
Infinity II M							2,8	2,9	3,1	3,3	3,4	3,6	3,8				
Infinity II L											3,1	3,3	3,4	3,6	3,7	3,9	4,0

